

# HF5111B

## Serial Server Device User Manual

V 1.1



### Overview of Characteristic

- ✧ Cortex-M3 MCU with 2MB Flash and 128KB SRAM
- ✧ Use FreeRTOS Operation System
- ✧ Support TCP/IP/Telnet /Modbus TCP Protocol
- ✧ Support Serial To 10/100M Ethernet Conversion, Serial Speed Upto 921600 bps
- ✧ Support 10/100M Ethernet Auto-Negotiation
- ✧ Support Easy Configuration Through a Web Interface or PC IOTManager Tool
- ✧ Support Security Protocol Such As TLS/AES/DES3
- ✧ Support Web OTA Wirelss Upgrade
- ✧ Support Industrial Temperature: -40 to +85° C
- ✧ Wide DC Input 5~36VDC or 9~50VDC
- ✧ Size: 94 x 65 x 25 mm (L x W x H)
- ✧ FCC/CE/RoHS Certificated

## TABLE OF CONTENTS TABLE OF CONTENTS

<b>TABLE OF CONTENTS TABLE OF CONTENTS .....</b>	<b>2</b>
<b>LIST OF FIGURES.....</b>	<b>5</b>
<b>LIST OF TABLES .....</b>	<b>7</b>
<b>HISTORY.....</b>	<b>7</b>
<b>1. PRODUCT OVERVIEW.....</b>	<b>8</b>
1.1. General Description .....	8
1.2. Device Features .....	8
1.3. Device Parameters.....	9
1.4. Key Application .....	10
<b>2. HARDWARE INTRODUCTION .....</b>	<b>11</b>
2.1. Pins Definition .....	12
2.2. RS232 Interface .....	13
2.3. RS485 Interface .....	14
2.4. RS422 Interface .....	14
2.5. RJ45 Interface .....	14
2.6. Mechanical Size .....	15
2.7. Rail Mounting .....	15
2.8. Order Information .....	16
2.9. Device Difference.....	16
2.10. Package Information.....	16
<b>3. FUNCTIONAL DESCRIPTION.....</b>	<b>18</b>
3.1. Basic Network Protocol.....	18
3.2. Ethernet Interface Function .....	18
3.3. Typical Network Architecture .....	19
3.4. Working Mode .....	19
3.5.1. Transparent Transmission Mode .....	19
3.5.2. TCP Server.....	20
3.5.3. HTTP Mode .....	21
3.5.4. Telnetd Mode.....	23
3.5. AES/DES3/TLS Data Encryption.....	25
3.6. Keepalive .....	25
3.7. Timeout .....	26
3.8. Route Setup.....	26
3.9. UART Frame Scheme .....	27
3.9.1. UART Free-Frame .....	27
3.9.2. UART Auto-Frame.....	28
3.9.3. Tag Function .....	28
3.10. Modbus Protocol.....	29
3.11. Cli Command .....	29
3.12. UART Flow Control and RS485 Function .....	30

3.13.	<b>Firmware Upgrade</b> .....	<b>30</b>
3.14.	<b>Web Page Function</b> .....	<b>31</b>
3.15.	<b>Auto-IP Function</b> .....	<b>31</b>
3.16.	<b>Other Function</b> .....	<b>32</b>
3.17.	<b>NTP Function</b> .....	<b>33</b>
3.18.	<b>Heartbeat Function</b> .....	<b>33</b>
3.19.	<b>UART Fast Config</b> .....	<b>34</b>
<b>4.</b>	<b>CLI COMMAND NOTES</b> .....	<b>35</b>
4.1.	<b>Working Mode</b> .....	<b>35</b>
4.1.1.	Switch Transparent Transmission Mode to Cli Command Mode .....	35
4.2.	<b>Cli Command Overview</b> .....	<b>36</b>
4.2.1.	Cli Command Format .....	39
4.2.1.1.	Show Command .....	39
4.2.1.2.	SYS Directory .....	40
4.2.1.3.	SYS/Auth Directory .....	40
4.2.1.4.	SYS/Auth/User Command.....	40
4.2.1.5.	SYS/Auth/Password Command .....	41
4.2.1.6.	SYS/Network Directory.....	41
4.2.1.7.	SYS/Network/Show Command .....	41
4.2.1.8.	SYS/Network/DHCP Command .....	41
4.2.1.9.	SYS/Network/DNS Command .....	41
4.2.1.10.	SYS/Network/Hostname Instruction .....	42
4.2.1.11.	SYS/Telnet Instruction.....	42
4.2.1.12.	SYS/Web Instruction .....	42
4.2.1.13.	SYS/MAC Instruction.....	43
4.2.1.14.	SYS/JCMD Instruction.....	43
4.2.1.15.	SYS/NTP Instruction.....	43
4.2.1.16.	UART Directory .....	43
4.2.1.17.	UART/Show Instruction .....	44
4.2.1.18.	UART/Baudrate Instruction.....	44
4.2.1.19.	UART/Databits Instruction .....	44
4.2.1.20.	UART/Stopbits Instruction .....	44
4.2.1.21.	UART/Parity Instruction .....	45
4.2.1.22.	UART/Buf Directory .....	45
4.2.1.23.	UART/Buf/Bufsize Instruction .....	45
4.2.1.24.	UART/Buf/GapTime Instruction .....	45
4.2.1.25.	UART/Buf/FlowCtrl Command.....	46
4.2.1.26.	UART/Buf/SWFlowCtrl Command.....	46
4.2.1.27.	UART/Cli-Getin Command .....	46
4.2.1.28.	UART/Cli-WaitTime Command.....	47
4.2.1.29.	UART/Proto command .....	47
4.2.1.30.	UART/Frame Directory .....	47
4.2.1.31.	UART/Frame/FrameLen Command .....	47
4.2.1.32.	UART/Frame/FrameTime Command .....	48

4.2.1.33. UART/Frame/Tag Command.....	48
4.2.1.34. UART/Edit Command.....	48
4.2.1.35. UART/Clean Command.....	48
4.2.1.36. SOCK Directory.....	49
4.2.1.37. SOCK/Show Command.....	49
4.2.1.38. SOCK/New Command.....	49
4.2.1.39. SOCK/netp directory.....	51
4.2.1.40. SOCK/netp/clean Command.....	51
4.2.1.41. DATA Directory.....	51
4.2.1.42. Restart Command.....	51
4.2.1.43. Reload Instruction.....	52
4.2.1.44. Exit Command.....	52
4.2.1.45. Quit Command.....	52
4.2.1.46. FwUpgrade Instruction.....	52
<b>APPENDIX A:REFERENCES.....</b>	<b>53</b>
<b>A.1. Test Tools.....</b>	<b>53</b>
<b>B.3. Quick Start Manual.....</b>	<b>53</b>
<b>APPENDIX B:TELNET COMMUNICATION FUNCTION.....</b>	<b>54</b>
<b>B.1. Telnet Use Scene:.....</b>	<b>54</b>
<b>B.2. Telnet Features:.....</b>	<b>54</b>
<b>B.3. Telnet Usage:.....</b>	<b>54</b>
<b>APPENDIX C: CONTACT INFORMATION.....</b>	<b>58</b>

## LIST OF FIGURES

Figure 1.	HF5111B Appearance .....	11
Figure 2.	HF5111B Interface.....	12
Figure 3.	HF5111B Side View.....	12
Figure 4.	RS232 Pin Defination(Male/Needle Type) .....	13
Figure 5.	HF5111B RS422 Connectioin.....	14
Figure 6.	RJ45 Pin Defination .....	14
Figure 7.	HF5111B Mechanical Dimension.....	15
Figure 8.	HF5111B Rail .....	16
Figure 9.	HF5111B Product Order Information .....	16
Figure 10.	HF5111 Software Protocol Structure .....	18
Figure 11.	Ethernet Interface Function.....	18
Figure 12.	Network application .....	19
Figure 13.	Transparent data transmission example .....	20
Figure 14.	TCP Server data transmission example .....	21
Figure 15.	Multi Socket data transmission example.....	21
Figure 16.	Webpage set up multi Socket channel.....	21
Figure 17.	IOTManager Software Configure .....	22
Figure 18.	Web Page Configure .....	22
Figure 19.	HTTP transmit example .....	23
Figure 20.	IOTManager Software Configure Protocol.....	24
Figure 21.	Web page configure protocol.....	24
Figure 22.	Telnet details example.....	25
Figure 23.	IOTManager Software Configure Encryption .....	25
Figure 24.	Web Page Configure Encryption.....	25
Figure 25.	Web Page Config Keepalive.....	26
Figure 26.	Web Page Configure Timeout.....	26
Figure 27.	Route function setup example .....	27
Figure 28.	Route Function Data Flow Example .....	27
Figure 29.	UART free-frame function.....	28
Figure 30.	UART Auto-Frame Function .....	28
Figure 31.	UART Auto-Frame Function .....	28
Figure 32.	UART Auto-Frame Tag Function .....	29
Figure 33.	UART Modbus Function.....	29
Figure 34.	Cli Command Setting.....	30
Figure 35.	UART Flow Control.....	30
Figure 36.	UART Half Duplex Function.....	30
Figure 37.	External web page .....	30
Figure 38.	Internal web page .....	31
Figure 39.	Web Page Function Setting .....	31
Figure 40.	AUTO-IP Connection .....	31
Figure 41.	AUTO-IP Config Device.....	32
Figure 42.	Cli Command Query Device IP .....	32
Figure 43.	Other Function .....	32

Figure 44.	IOTManager Tools NTP Setting.....	33
Figure 45.	Cli Command NTP Setting and Query .....	33
Figure 46.	Heartbeat Function .....	33
Figure 47.	HF5111 Default: UART Parameters .....	35
Figure 48.	Switch Transparent Transmission Mode to Cli Command Mode .....	36
Figure 49.	Cli Command Root Directory .....	36
Figure 50.	Cli Command SYS Tree.....	37
Figure 51.	Cli Command UART Tree .....	37
Figure 52.	Cli Command SOCK Tree.....	38
Figure 53.	Cli Other Command .....	39

## LIST OF TABLES

Table1.	HF5111B Technical Specifications .....	9
Table2.	HF5111B Interface Definition.....	13
Table3.	RS232 Interface.....	13
Table4.	RJ45 Interface .....	15

## HISTORY

<b>Ed. V1.0</b>	11-08-2016	First Version
<b>Ed. V1.1</b>	02-10-2017	Add Auto-IP, heartbeat, ntp and UART fast config function(Firmware version:1.07c)

# 1. PRODUCT OVERVIEW

## 1.1. General Description

The HF5111B provides a serial interface to Ethernet connectivity to web enable any device. The HF5111B integrate TCP/IP controller, memory, 10/100M Ethernet transceiver, high-speed serial port and integrates a fully developed TCP/IP network stack and FreeRTOS OS. The HF5111B also includes an embedded web server used to remotely configure, monitor, or troubleshoot the attached device.

The HF5111B using highly integrated hardware and software platform, It has been optimized for all kinds of applications in the industrial control, smart grid, personal medical application and remote control that have lower data rates, and transmit or receive data on an infrequent basis.

The HF5111B integrates all serial to Ethernet functionality with 94 x 65 x 25mm size..

## 1.2. Device Features

- Cortex-M3 MCU with 2MB Flash and 128KB SRAM
- Support FreeRTOS Operation System
- Support TCP/IP、UDP、DHCP、DNS、HTTP Server/Client、ARP、BOOTP、AutoIP、ICMP、Telnet、FTP、TFTP、uPNP、NTP、ModbusTCP Protocol
- Support Serial to 10/100M Ethernet Conversion, Serial Speed Upto 460800 bps
- Support 10/100M Ethernet Auto-Negotiation
- Support Easy Configuration Through a Web Interface
- Support Security Protocol Such As TLS/AES/DES3
- Support Web Wireless Upgrade
- Support Industrial Temperature: -40 to +85° C
- Wide 5~36VDC or 9~50VDC Power Supply
- Size: 94 x 65 x 25mm (L x W x H)
- FCC/CE/RoHS Certificated



### 1.3. Device Parameters

Table1. HF5111B Technical Specifications

Item	Parameters
<b>System Information</b>	
Processor/Frequency	Cortex-M3/96MHz
Flash/SDRAM	2MB/128KB
Operating System	FreeRTOS
<b>Ethernet Port</b>	
Port Number	1 RJ45
Interface Standard	10/100 Base-T Auto-Negotiation
Protection	8KV Isolation
Transformer	Integrated
Network Protocol	IP, TCP, UDP, DHCP, DNS, HTTP Server/Client, ARP, BOOTP, AutoIP, ICMP, Web socket, Telnet, FTP,TFTP, uPNP, NTP, SNMP,Modbus TCP
Security Protocol	TLS v3 AES 128Bit DES3
IPV6 Support	Not yet
<b>Serial Port</b>	
Port Number	1 RS232/RS485/RS422
Interface Standard	RS232: DB9 RS485/RS422: 5.08mm connector
Data Bits	8
Stop Bit	1,2
Check Bit	None,Even,Odd,Space,Mark
Baud Rate	TTL: 600 bps~460800 bps
Flow Control	No Flow control Hardware RTS/CTS、DSR/DTR Software Xon/ Xoff flow control
<b>Software</b>	
Web Pages	Http Web Configuration Customization of HTTP Web Pages
Configuration	Web CLI XML import Telnet IOTManager PC Software
Firmware Upgrade	Web
SDK For Dev.	Not yet
<b>Basic Parameter</b>	
Size	94 x 65 x 25 mm
Operating Temp.	-45 ~ 85°C
Storage Temp.	-45 ~ 105°C, 5 ~ 95% RH (no condensation)
Input Voltage	5~36VDC or 9~50VDC
Working Current	~100mA

Power	<400mW
<b>Other Information</b>	
Certificate	CE, FCC, RoHS

#### 1.4. Key Application

The HF5111B device connects serial device to Ethernet networks using the TCP/IP protocol:

- Remote equipment monitoring
- Asset tracking and telemetry
- Security Application
- Industrial sensors and controls
- Medical devices
- ATM machines
- Data collection devices
- Universal Power Supply (UPS) management units
- Telecommunications equipment
- Data display devices
- Handheld instruments
- Modems
- Time/attendance clocks and terminals

## 2. HARDWARE INTRODUCTION

The HF5111B unit is a complete solution for serial port device connecting to network. This powerful device supports a 10/100BASE-T Ethernet connection, a reliable and proven operating system stored in flash memory, an embedded web server, a full TCP/IP protocol stack, and standards-based (AES) encryption.

Through Ethernet cable connect router with HF5111B serial server for data transfer, which makes the data transformation very simple. HF5111B meet EMC Class B security level, It can pass every countries relevant certification test



Figure 1. HF5111B Appearance

## 2.1. Pins Definition




Figure 2. HF5111B Interface




Figure 3. HF5111B Side View

Table2. HF5111B Interface Definition

Function	Name	Description
External Interface	RJ45 Ethernet	10/100M Ethernet
	RS232	RS232 Communication
	RS485/RS422	RS485/RS422 Communicaton
	Earth	Protect Earth
	DC Input	DC Power 5~36V Input or 9~50VDC
LED Indicator	Power	Internal Power Supply Indicator On : Power is OK Off : Power is NG
	Link	Connection Indicator On: Ethernet connection is OK Off: No Ethernet connection
	Active	Data transfer Indicator On : Data is transferring. Off : No data transfer
Button	Reset	Reset device
Switch	Protect	Device parameter protect On: Enable protect, working parameter can not be modified. Off: Disable protect.

## 2.2. RS232 Interface

Device serial port is male(needle), RS232 voltage level(can connect to PC directly), Pin Order is consistent with PC COM port. Use cross Cable connected with PC(2-3 cross, 7-8 cross, 5-5 direct, 7-8 no connection), see the following table for pin defination.



Figure 4. RS232 Pin Defination(Male/Needle Type)

Table3. RS232 Interface

Pin Number	Name	Description
2	RXD	Receive Data
3	TXD	Send Data
5	GND	GND

Pin Number	Name	Description
7	RTS	Request to Send
8	CTS	Clear to Send

### 2.3. RS485 Interface

RS485 use two wire links, A(DATA+), B(DATA-). Connect A(+) to A(+), B(-) to B(-) for communication.

The RS485 interface support maximum 32 485 device, special hardware version can support max 255 device. The cable maximum length is 1200 meters. Need to add 120Ohm terminal resistor for over 300 meters.

### 2.4. RS422 Interface

RS422 interface use T+/T-/R+/R-, cross connect to device as the following picture.

Name	Description
TX+	Transfer Data+
TX-	Transfer Data-
RX+	Receive Data+
RX-	Receive Data-




Figure 5. HF5111B RS422 Connection

### 2.5. RJ45 Interface

Ethernet port is 10M/100M adaptive, support AUTO MDI/MDIX which means it support direct connecting to PC with Ethernet cable.




Figure 6. RJ45 Pin Definition

Table4. RJ45 Interface

Pin Number	Name	Description
1	TX+	Transfer Data+
2	TX-	Transfer Data-
3	RX+	Receive Data+
4	PHY-VCC	Transformer Tap Voltage
5	PHY-VCC	Transformer Tap Voltage
6	RX-	Receive Data-
7	N.C.	None Connect
8	N.C.	None Connect

## 2.6. Mechanical Size

The dimensions of HF5111B are defined as following picture (mm):



Figure 7. HF5111B Mechanical Dimension

## 2.7. Rail Mounting

We support to provide rail for mounting as the following picture.




Figure 8. HF5111B Rail

## 2.8. Order Information

Base on customer detailed requirement, HF5111B provide different configuration version, Details as below:




Figure 9. HF5111B Product Order Information

## 2.9. Device Difference

The device difference is as following

Type	RS232	RS485/RS422	Ethernet	OS	Voltage	Size (mm)
HF5111B(-H)	√	√	√	Linux	5~36V	94*65*25
HF5111B-I	√	√	√	Linux	9~50V	94*65*25
HF5111B(-H)	√	√	√	FreeRTOS	5~36V	94*65*25
HF5111B-I	√	√	√	FreeRTOS	9~50V	94*65*25

## 2.10. Package Information

1 \* HF5111B



1 \* 12V/1A DC adapter

1 \* RS232 cable

1 \* Ethernet cable

IOT WORKSHOP

### 3. FUNCTIONAL DESCRIPTION

The HF5111 has the following feature:

- Connect customer’s device with PC or server via TCP/UDP/Telnet.
- Contain a HTTP web server allow user to configure through browser with PC or phone.
- Have multi-programmable I/O pins used to monitor or control device directly.

#### 3.1. Basic Network Protocol

The HF5111 device uses the IP address for network communications. If uses the TCP to assure that no data is lost or duplicated. If use UDP to assure that data can be fast and effective to destination address.

Supported protocols include:

- ARP, UDP, TCP, ICMP, DHCP, Telnet, DHCP, HTTP Server/Client Web socket
- Telnet command configuration, Web server configuration
- Security Protocol: TLS, AES, DES3 encryption




Figure 10. HF5111 Software Protocol Structure

#### 3.2. Ethernet Interface Function



Figure 11. Ethernet Interface Function

The HF5111 device Ethernet interface work in WANN function by default. When connect to router, it will get IP address from router(as picture 192.168.1.100). Then the device and the PC1 are in the same local area network(LAN) for network communication, The data of communication finally pass from UART to network to control or collect PLC device.

Notes:

The device support RS232/RS422/RS485 interface. Choose one of these three data interface .

### 3.3. Typical Network Architecture

As the following picture, HF5111 and mobile device all connect to the same Router AP. At the same time, HF5111 connect to user equipment by RS232/RS422/RS485 interface. The whole wireless network is easily to extend in this kind of network structure.



Figure 12. Network application

### 3.4. Working Mode

#### 3.5.1. Transparent Transmission Mode

The HF5111 Device support transparent transmission mode of serial interface, In this mode, User only need to set some necessary parameter(network communication parameter). After power on, the

device can auto connect to default socket setting(TCP/UDP). Use web page or PC IOTManager software to set commucation parameter.




Figure 13. Transparent data transmission example

### 3.5.2. TCP Server

Transparent transmission mode support TCP Server、TCP Client、UDP Server、UDP Client communication application, UDP Server is special function, Details see following Cli instruction. There is a default tcp server socket created. The Socket can be modified to work at one of the above working mode. When Socket works as TCP server, It will support multiple TCP connection(max 5 TCP client). Multiple TCP connection will work in below structure:

Upload data flow: All the different TCP connection or the Client's data will be continuously transmitter to UART.

Download data flow: All data received from UART will be copied and broadcast to every TCP client.

Detailed multiple TCP connection structure drawing as below:




Figure 14. TCP Server data transmission example

The device support max 5 Socket channel, each socket can work individual at TCP/UDP, Multi Socket simultaneous communication of data stream is as following.




Figure 15. Multi Socket data transmission example

Multi Socket can be created through software configure or webpage configure. The below set up 3 socket channel.




Figure 16. Webpage set up multi Socket channel

### 3.5.3. HTTP Mode

Eport –E10 device support sending data in HTTP format to HTTP server(Set product working mode by IOTManager software or webpage). When device socket works in HTTP mode, All received UART data will automatically transform to HTTP format(add HTTP header) and transmit to HTTP server. For the received HTTP data from HTTP server, will automatically remove HTTP header and only output the data packet to UART.




Figure 17. IOTManager Software Configure




Figure 18. Web Page Configure

HF5111 UART received“pppp”data, send below data to HTTP Server.

GET /abcdefg HTTP/1.1

api-key: A4hQnojCHf8PurykvCHvsQ4JCMM=

pppp

HTTP Server send below data, HF5111 serial output“abcde”

GET /abcdefg HTTP/1.1

api-key: A4hQnojCHf8PurykvCHvsQ4JCMM=

abcde




Figure 19. HTTP transmit example

### 3.5.4. Telnetd Mode

When device work in Telnetd mode, UART port can connect to user device console port(some gateway and switch device may have this console port to set parameters of its working mode). May use HF5111 to config user device via Telnetd mode.




Figure 20. IOTManager Software Configure Protocol




Figure 21. Web page configure protocol

Connect device UART to user device console port(The example use NC916) and create Telnet connection. Then It can directly configure user device.






Figure 22. Telnet details example

### 3.5. AES/DES3/TLS Data Encryption

To improve device security and ensure the data won't be cracked and illegal used, The HF5111 device can do encryption to UART data before transmit to network.




Figure 23. IOTManager Software Configure Encryption





Figure 24. Web Page Configure Encryption

### 3.6. Keepalive

When TCP connection between device and server became abnormal. The device will check the abnormal status and reconnect to server ( when the device working in TCP Client Mode), When the device working in TCP Server, It will break the TCP client and wait for next connection.

## Communication Settings

change the device socket settings




Basic Settings	
Name	netp
Local Port	8899
Buffer Size	512
Keep Alive (s)	10
Timeout (s)	300

Figure 25. Web Page Config Keepalive

### 3.7. Timeout

The device will break the TCP connection after some time (default is 300 seconds and it can be modified) if there is no data packet received from destination TCP target. It will reconnect to server (When device works in TCP Client mode). When device working in TCP Server, It will disconnect with TCP Client. This mechanism can effectively restore TCP abnormal connection. If set it to "0", this function will be close.



Basic Settings	
Name	netp
Local Port	8899
Buffer Size	512
Keep Alive (s)	10
Timeout (s)	300

Figure 26. Web Page Configure Timeout

### 3.8. Route Setup

The data received from Socket channel can be set to another socket channel. (Default: socket destination channel is UART, It also can be other Socket channel, Or take the Socket as log print usage)

The below example shows the default netp Socket channel route setting to Socket1, Socket1 configure as TCP Server mode and route setting to UART. So the netp Socket channel received UART data will output to Socket1, and Socket1 channel will output to serial output.




Figure 27. Route function setup example




Figure 28. Route Function Data Flow Example

### 3.9. UART Frame Scheme

#### 3.9.1. UART Free-Frame

HF5111 support UART Free-Frame function, If user select to open this function, Module will check the intervals between any two bytes when receiving UART data, If the interval time exceed the setting value, It will think it as the end of one frame, Or it will receive data till greater than internal buffer bytes( Default: 512, the largest 1400 bytes), then transfer to Socket Channel.

Module default UART Free-Frame interval time is 50ms, it will packaged into another frame if received UART data interval time is greater than 50ms. User also can set this interval time to minimum 10ms through Cli command and webpage.

If interval time is set to 10ms and customer MCU can't send next byte within 10ms, The serial data will be break into two frame.




Figure 29. UART free-frame function

### 3.9.2. UART Auto-Frame

HF5111 support UART Auto-Frame function, If user select to open this function, setting frame trigger length and auto frame trigger time parameters, Then the product will auto framing the data which received from UART port and transmitting to the network as pre-defined data structure.

Auto-Frame trigger length: The fixed data length that product used to transmitting to the network.

Auto-Frame trigger time: After the trigger time, If UART port received data can't reach auto-frame trigger length, Then product will transmitting available data to network and bypass the auto-frame trigger length condition.




Figure 30. UART Auto-Frame Function





Figure 31. UART Auto-Frame Function

### 3.9.3. Tag Function

Eport E10 support lable function, If user select to open this function, The UART port will send all suitable one frame data to network.




The screenshot shows the 'Protocol Settings' interface. It includes the following fields:

- Protocol:** A dropdown menu set to 'Frame'.
- Frame Length:** A text input field containing '50'.
- Frame Time (ms):** A dropdown menu set to '100'.
- Tag:** A toggle switch currently turned 'ON'.
- Tag Head:** A text input field containing '00'.
- Tag Tail:** A text input field containing '00'.

Figure 32. UART Auto-Frame Tag Function

### 3.10. Modbus Protocol

HF5111 support ModbusRTU to ModbusTCP and ModbusTCP to ModbusRTU. It's very convenient to connect with Modbus device. Modbus protocol setting as below:




The screenshot shows the 'Protocol Settings' interface with the 'Protocol' dropdown menu set to 'Modbus'.

Figure 33. UART Modbus Function

### 3.11. Cli Command

Cli command is used for setting module configure parameters. Detailed command function and setting is in next chapter, Cli command can be set through UART port or Telnet function (Appendix C), The waiting time of below picture means use timeout time. If it exceed default 300s when no Cli command is input, it will exit Cli command mode. When the HF5111 receive continuous UART data of "+++", it will enter into Cli command. ( The device working in transparent transmission mode by default) May also set the device working in Cli command mode by default or disable this function .



The screenshot shows the 'Cli Settings' interface. It includes the following fields:

- Cli:** A dropdown menu set to 'Serial String'.
- Serial String:** A text input field containing '+++ '.
- Waiting Time:** A dropdown menu set to '300|'.

Figure 34. Cli Command Setting

### 3.12. UART Flow Control and RS485 Function

HF5111 support software and hardware UART flow control. If use hardware follow control, must use RS232 interface. If use software follow control, then It allowed the device output UART data after receive single UART 0x11 data(Default: value can be modified). It will stop output UART data after receive single UART 0x13 data(Default: value can be modified).




Figure 35. UART Flow Control

If set to “Half Duplex”, the product enable RS485 interface, it is by default enabled.



Figure 36. UART Half Duplex Function

### 3.13. Firmware Upgrade

HF5111 support OTA(over the air) firmware upgrade. User can use webpage to upgrade its firmware, whether external or internal webpage(192.168.0.101/hide. Internal webpage can be used for upgrade external webpage). Please check below example. IP address is assigned by router.



Figure 37. External web page




Figure 38. Internal web page

### 3.14. Web Page Function

Web page function can be enabled or disabled.



Figure 39. Web Page Function Setting

### 3.15. Auto-IP Function

Connect device Ethernet with PC, the device will use default auto IP. The PC may use this IP to config the device or transfer data(PC will need about 15 seconds to use default 169.254.xxx.xxx IP, then this communication can be created). As the following example, 169.254.173.207(If occur IP conflict, it will use other ip instead)



Figure 40. AUTO-IP Connection




Figure 41. AUTO-IP Config Device

```

EPORT>Show

===System State===
Product ID:HF5111B
Software Version:V1.07c
Config Protected:OFF
System time:NTP Disabled
Up Time: 0-Day 0:1:36
Total Free Memory: 40320
MAX Block size:38568

===NETWORK===
MAC:FOFE6B1C3D35
Ip Address:169.254.173.207
Gateway:0.0.0.0
    
```

Figure 42. Cli Command Query Device IP

### 3.16. Other Function

The HF5111 device parameters can be exported and loaded into other equipment..




Figure 43. Other Function



### 3.17. NTP Function

Support NTP function(default is disabled). Support set NTP server, port, time zone information, more detailed usage see application document of “UART Fast Config”.(112.124.43.15 is High-Flying test NTP server)




Figure 44. IOTManager Tools NTP Setting

```

EPORT>SYS NTP
Enable
Server:112.124.43.15
Port:123
GMT:8
EPORT>Show

===System State===
Product ID:HF5111B
Software Version:V1.07c
Config Protected:OFF
System time:2017-1-23 13:48:38 Mon
Up Time: 0-Day 2:44:32
Total Free Memory: 32880
MAX Block Size:31164
    
```

Figure 45. Cli Command NTP Setting and Query

### 3.18. Heartbeat Function

Support heartbeat function, can set the heartbeat time and content(heartbeat time is the same as keepalive setting), if the product does not receive data from TCP server within heartbeat time, it will send heartbeat to server. The heartbeat function can only be enabled when socket is set as TCP client.




Figure 46. Heartbeat Function

### 3.19. UART Fast Config

Product support Cli command to config its parameters, but also support special HEX format UART data for fast config, see application manual for detailed usage.

IOT WORKSHOP

## 4. CLI COMMAND NOTES

### 4.1. Working Mode

The device will enter into default transparent transmission mode after powered on. User can switch to Cli command mode through special UART data. Module default UART parameters are as below:




Figure 47. HF5111 Default: UART Parameters

In Command mode, User can use UART port to set module through Cli command.

**Notes:**

We recommend to use SecureCRT for UART debug tools.

#### 4.1.1. Switch Transparent Transmission Mode to Cli Command Mode

**Steps:**

- Input “+++” via UART tools, the device will output “EPORT>” after received“+++”. Then the device already enters into Cli command mode.

**Notes:**

”+++” should be in one frame. Other data is not allowed before or after “+++”




Figure 48. Switch Transparent Transmission Mode to Cli Command Mode

**<Notes>:**

In Cli command mode, users can set or query parameters. Cli command details see next chapter

**4.2. Cli Command Overview**

Cli command can be input through terminal (SecureCRT or other UART tools) or by user device MCU programming. As below picture, we use SecureCRT tool. Press “Tab” key, it will list current available Cli command or directory. If input first character and then press “Tab” key, it will show the Cli command fit with the first character.




Figure 49. Cli Command Root Directory

SYS	Version		
	Auth	user	
		password	
		quit	
	Network	Show	
		DHCP	Enable
			Disable
		ip address	
		gateway	
		DNS	
		HostName	
	Quit		
	Telnet	Enable	port number
		echo	
	Web	Disable	
		Enable	port number
	MAC		
	JCMD	Enable	
		Disable	
	NTP	Enable	NTP Server Address
NTP Server port			
GMT			
	Disable		
Quit			

Figure 50. Cli Command SYS Tree

UART	Show		
	Baudrate		
	Databits		
	Stopbits		
	Parity		
	Buf	BufSize	
		GapTime	
		Quit	
	FlowCtrl	FlowCtrl	
		Half-Duplex	
		Disable	
	SWFlowCtrl	Enable	
		Disable	
	Cli-Getin	Disable	
		Serial-String	
		Always	
	Cli-WaitTime		
	Proto	NONE	
		Modbus	
		Frame	
	Frame	FrameLen	
		FrameTime	
Tag			
Quit			
Edit			
Clean			
Quit			

Figure 51. Cli Command UART Tree




Figure 52. Cli Command SOCK Tree

DATA	Str
	Hex
	Quit
FwUpgrade	
Restart	
Reload	
Exit	

Figure 53. Cli Other Command

### 4.2.1. Cli Command Format

Cli command is in ASCII format. The usage is similar to Linux terminal. Command format as following:

➤ Format Notes

- <>: Cli command name or directory.
- [ ]: Cli command parameters.

➤ Command Message

**<CMD> [para-2 para-3 para-4...]<CR>**

- <CMD>: Main directory or command name;
- [para-n] : command parameters. If have multiple directory, it can also can be the son directory. As below example;

```
EPORT>SYS Auth
User Password Quit
```

- <CR>: Command Terminator, "Enter" key, HEX data: 0x0a or 0x0d

**<Notes>**

If the input command not existed, UART will output again "EPORT>" to allow next command input. The Cli command is case sensitive.

```
EPORT>sys
EPORT>SYS
EPORT/SYS>
```

If need enter into son directory, press "space" key between the directories.

```
EPORT>SYS Auth
EPORT/SYS/Auth>
```

If need to display all the directory or commands in the current directory, press "Tab" key to query.

```
EPORT/SYS>
Auth Network Telnet web Ipv6
MAC JCMD Quit
```

If need to display current command parameter, press Tab key to query.

```
EPORT/SYS/Network>DHCP
Enable Disable
```

4.2.1.1. Show Command

- Function: Show all system information, including the system running status, Network status, UART status and socket status.
- Format:
  - ◆ Query

**Show [SYS/UART/SOCK]**

- Parameter:
  - Show all information if no parameters. Parameter can be one of the following:
    - ◆ SYS: System running status
    - ◆ UART: UART status
    - ◆ SOCK: Socket status

```

EPORT>Show
===System State===
Product ID:E-10
Software Version:V1.04
Up Time: 0-Day 0:21:39
Total Free Memory: 48400
MAX Block Size:46816
===NETWORK===
MAC:ACCF23FF4771
Ip Address:192.168.0.106
Gateway:192.168.0.1
===UART Status===
Config:115200,8,1,NONE,NONE
State:In CLI
Recv Bytes:26      Recv Frames:24
Send Bytes:0       Send Frames:0
Failed Bytes:0     Failed Frames:0
===SOCK Status===
SOCK Name:netp
State:Server Created
Client IP:
Recv Bytes:0       Recv Frames:0
Send Bytes:0       Send Frames:0
Failed Bytes:0     Failed Frames:0
    
```

4.2.1.2. SYS Directory

- Function: Display/Set all system related information
- Format:
  - ◆ Tab Query

```

EPORT/SYS>
Version Auth      Network Telnet  web
NTP      MAC      JCMD      Quit
    
```

4.2.1.3. SYS/Auth Directory

- Function: Display/Set web or Telnet Cli command login directory. (see appendix for detail)
- Format:
  - ◆ Tab Query

```

EPORT/SYS/Auth>
User      Password      Quit
    
```

4.2.1.4. SYS/Auth/User Command

- Function: Display/Set web or Telnet Cli command login user name. (function see appendix)
- Format:
  - ◆ Query
    - <User>
  - ◆ Set
    - <User> [value]
- Parameter:
  - Setting is valid immediately.
    - ◆ User: Login user name. Default: **admin**



- ◆ value: set value. Length range 1~29 characters

#### 4.2.1.5. SYS/Auth/Password Command

- Function: Display/Set web or Telnet Cli command login password(function see appendix)
- Format:
  - ◆ Query
    - <Password>**
    - ◆ Set
      - <Password> [value]**
  - Parameter:
    - Setting is valid immediately
    - ◆ Password: Login password. Default: **admin**
    - ◆ value: set value. Length range 1~29 characters

#### 4.2.1.6. SYS/Network Directory

- Function: Display/Set related network information.
- Format:
  - ◆ Tab Query

EPORT/SYS/Network>				
Show	DHCP	DNS	HostName	Quit

#### 4.2.1.7. SYS/Network/Show Command

- Function: Display network related information
- Format:
  - ◆ Query
    - <Show>**

#### 4.2.1.8. SYS/Network/DHCP Command

- Function: Display/Set DHCP Client function
- Format:
  - ◆ Query
    - <DHCP>**
    - ◆ Set
      - <DHCP> [Enable/Disable]**
  - Parameter:
    - Setting is valid after reboot.
    - ◆ Enable: Enable DHCP function. The device will get DHCP IP from router when Ethernet port is connected to router LANN port. Default: **Enable**.
    - ◆ Disable: Disable DHCP function. Allocate device static IP address according to the hit of inputting IP and gateway address.

#### 4.2.1.9. SYS/Network/DNS Command

- Command: Display/Set DNS IP address.
- Format:
  - ◆ Query

**<DNS>**

- ◆ Set

**<DNS> [IP]**

- Parameter:  
When DHCP function is Disabled, this setting is valid. Setting is valid after reboot.
  - ◆ IP Address: DNS server address. Default: **10.10.100.254**.

## 4.2.1.10. SYS/Network/Hostname Instruction

- Function: Display/Set Hostname.
- Format:
  - ◆ Query

**<Hostname>**

- ◆ Set

**<Hostname> [name]**

- Parameter:  
Hostname is the name which show in router DHCP client list. Setting is valid immediately.
  - ◆ Name Address: Hostname, length range: 1~30 characters. Default: **HF5111**.

## 4.2.1.11. SYS/Telnet Instruction

- Function: Display/Set Telnet function.
- Format:
  - ◆ Query

**<Telnet>**

- ◆ Set

**<Telnet> [Enable/Disable]**

- Parameter:  
See appendix for detailed Telnet function usage. Telnet is used for remote send Cli command or transmit data, Setting is valid after reboot.
  - ◆ Enable: Enable Telnet function. Default: **Enable**.
    - Input Port Number: Telnet Port Number. Default: **23**
    - Input Echo Mode: Enable/Disable Cli command echo function. Default: **Enable**
  - ◆ Disable: Disable Telnet function.

## 4.2.1.12. SYS/Web Instruction

- Function: Display/Set Web config function.
- Format:
  - ◆ Query

**<Web>**

- ◆ Set

**<Web> [Enable/Disable]**

- Parameter:  
Webpage is used for config module working parameters. Setting is valid after reboot.
  - ◆ Enable: Enable Web config function. Default: **Enable**.

- Input Port Number: Web Port Number. Default: **80**
- ◆ Disable: Disable Web config function

#### 4.2.1.13. SYS/MAC Instruction

- Function: Display/Set MAC address.
- Format:
  - ◆ Query
  - <MAC>**
  - ◆ Set
  - <MAC> [8888 value]**
- Parameter:
 

Global unique MAC Address. It is not allowed to modify it.

  - ◆ value: MAC address value.

#### 4.2.1.14. SYS/JCMD Instruction

- Function: Display/Set Jason command function.
- Format:
  - ◆ Query
  - <JCMD>**
  - ◆ Set
  - <JCMD> [Enable/Disable]**
- Parameter:
 

Jason command is used for config module. IOTManage software use this mechanism. If disable JCMD function, IOTManage is no longer valid. Setting is valid after reboot.

  - ◆ Enable: Enable JCMD function. Default: **Enable**.
  - ◆ Disable: Disable JCMD function.

#### 4.2.1.15. SYS/NTP Instruction

- Function: Display/Set NTP function.
- Format:
  - ◆ Query
  - <NTP>**
  - ◆ Set
  - <NTP> [Enable/Disable]**
- Parameter:
 

NTP is used for product to get and output real time. See uart fast config application manual to fast query. Setting is valid immediately.

  - ◆ Enable: Enable NTP Function.
    - NTP Server Address: NTP Server address, domain name or IP address
    - NTP Server Port: port number, Default:123, Range;0~127
    - GMT: Time zone, default is 0, Range:-12~12.
  - ◆ Disable: Disable NTP Function, Default value.

#### 4.2.1.16. UART Directory

- Function: Display/Set UART information directory.

- Format:
  - ◆ Tab key query

EPORT/UART>	Baudrate	Databits	Stopbits	Parity
Show	FlowCtrl	SWFlowCtrl	Cli-Getin	Cli-waitTime
Buf	Frame	Edit	Clean	Quit
Proto				

#### 4.2.1.17. UART/Show Instruction

- Function: Display UART information function.
- Format:
  - ◆ Query

**<Show>**

#### 4.2.1.18. UART/Baudrate Instruction

- Function: Display/Set UART baud rate function.
- Format:
  - ◆ Query

**<Baudrate>**

- ◆ Set

**<Baudrate> [value]**

- Parameter:
  - Setting is valid immediately.
  - ◆ Value: Default: **115200**. Can choose 2400, 4800, 9600, 38400, 57600, 115200, 230400, 460800

#### 4.2.1.19. UART/Databits Instruction

- Function: Display/Set UART data bits function.
- Format:
  - ◆ Query

**<Databits>**

- ◆ Set

**<Databits> [value]**

- Parameter:
  - Setting is valid immediately.
  - ◆ Value: Default: **8bits**. Can choose 5, 6, 7, 8.

#### 4.2.1.20. UART/Stopbits Instruction

- Function: Display/Set UART stop bits function.
- Format:
  - ◆ Query

**<Stopbits>**

- ◆ Set

**<Stopbits> [value]**

- Parameter:
  - Setting is valid immediately.
  - ◆ Value: Default: **1bits**. Can choose 1, 1.5, 2.

## 4.2.1.21. UART/Parity Instruction

- Function: Display/Set UART parity function.
- Format:
  - ◆ Query  
**<Parity>**
  - ◆ Set  
**<Parity> [value]**
- Parameter:
  - Setting is valid immediately.
  - ◆ Value: Default: **None**. Can choose NONE, EVEN, ODD.

## 4.2.1.22. UART/Buf Directory

- Function: Display/Set UART Buffer directory.
- Format:
  - ◆ Tab key query

```
EPORT/UART/Buf>
BufSize GapTime Quit
```

## 4.2.1.23. UART/Buf/Bufsize Instruction

- Function: Display/Set UART buffer size function.
- Format:
  - ◆ Query  
**<Bufsize>**
  - ◆ Set  
**<Bufsize> [value]**
- Parameter:
  - Buffer is used for cache UART received data. If the received data of one frame is larger than buffer size. The data frame will be break into two packet send to network. Setting is valid after reboot.
  - ◆ Value: Default: **512**. Length range: 32~1400 bytes.

## 4.2.1.24. UART/Buf/GapTime Instruction

- Function: Display/Set UART free frame gap time.
- Format:
  - ◆ Query  
**<GapTime>**
  - ◆ Set  
**<GapTime> [value]**
- Parameter:
  - GapTime is used for setting UART free frame time gap. If the received data gap time is more than setting value, the data packet will be broken into two frame.
  - ◆ Value: Default: **50ms**. Length Range: 10~1000ms.

## 4.2.1.25. UART/Buf/FlowCtrl Command

- Function: Display/Set UART flow control function.
- Format:
  - ◆ Query
  - <FlowCtrl>**
  - ◆ Set
  - <FlowCtrl> [Enable/Disable]**
- Parameter:
 

Flow control includes software flow control and hardware flow control. Software flow control priority is higher than hardware. If enable software flow control, the hardware flow control pin(CTS/RTS) will be useless. Software flow control use special UART data for control. Hardware flow control use CTS/RTS pin control. Setting is valid immediately.

  - ◆ Flow Control: Flow control function.
  - ◆ Half-Duplex: Enable RS485 half-duplex function, UART0\_RTS is used for RS485 chip control function.
  - ◆ Disable: Flow control function. Default: **Disable**.

## 4.2.1.26. UART/Buf/SWFlowCtrl Command

- Function: Display/Set UART software flow control function.
- Format:
  - ◆ Query
  - <SWFlowCtrl>**
  - ◆ Set
  - <SWFlowCtrl> [Enable/Disable]**
- Parameter:
 

Enable software flow control function. The device UART can output data After UART received Xon single-byte enable data. When UART received Xoff single-byte disable data. It will disable the device UART output data.

  - ◆ Enable: Enable software flow control function, When in enable status, it allow UART data output when bootup by default.
    - Xon: Enable UART output data. Default: **0x11**.
    - Xoff: Disable UART output data. Default: **0x13**.
  - ◆ Disable: disable software flow control function. Default: **Disable**.

## 4.2.1.27. UART/Cli-Getin Command

- Function: Display/Set Cli command function
- Format:
  - ◆ Query
  - <Cli-Getin>**
  - ◆ Set
  - <Cli-Getin> [Serial-String/Always/Disable]**
- Parameter:
 

Set Cli command parameters. Setting is valid immediately.

  - ◆ Serial-String: Enable specific data to enter into Cli command mode.

- [Input Serial String]: Default: **+++**, Range 1~10 bytes. Also can input hex format data. The HEX data are separated by Spaces, Like **【30 31 32 33 34】**, When it received string data "01234", then It can enter into Cli command.
- ◆ Always: Always work in Cli command mode when device power on.
- ◆ Disable: Disable Cli command mode. UART and Telnet both can't use Cli Command.

#### 4.2.1.28. UART/Cli-WaitTime Command

- Function: Display/Set Cli command wait time
  - ◆ Format
    - <Cli-WaitTime>**
    - ◆ Set
      - <Cli-WaitTime> [timeout]**
  - Parameter:
    - Set Cli command mode timeout exit time. If there is no Cli command sent for the waittime, It will exit Cli command mode to transparent transmission, Setting is valid immediately.
    - ◆ timeout: Default: **300s**, Range 0: Disable WaitTime function, 1~300s.

#### 4.2.1.29. UART/Proto command

- Function: Display/Set UART protocol function
- Format:
  - ◆ Query
    - <Proto>**
    - ◆ Set
      - <Proto> [NONE/Modbus/Frame]**
  - Parameter:
    - Setting is valid immediately.
    - ◆ NONE: Default: **None**, transparent transmission, the received UART data will be directly sent to network.
    - ◆ Modbus: Modbus RTU to Modbus TCP.
    - ◆ Frame: Enable auto-frame function. Relevant parameters are set in Frame command.

#### 4.2.1.30. UART/Frame Directory

- Function: Display/Set UART frame directory.
- Format:
  - ◆ Tab key query

```

EPORT/UART/Frame>
FrameLen      FrameTime      Tag      quit

```

#### 4.2.1.31. UART/Frame/FrameLen Command

- Function: Display/Set UART auto-frame frame length
- Format:
  - ◆ Query

**<FrameLen>**

- ◆ Set

**<FrameLen> [value]**

- Parameter:  
Set UART auto-frame length, Setting is valid immediately.
  - ◆ value: Default: **8**, Range: 8~1400.

## 4.2.1.32. UART/Frame/FrameTime Command

- Function: Display/Set UART auto-frame time
- Format:
  - ◆ Query

**<FrameTime>**

- ◆ Set

**<FrameTime> [value]**

- Parameter:  
Set UART auto-frame time, Setting is valid immediately.
  - ◆ value: Default: **100ms**, Range: 100~10000.

## 4.2.1.33. UART/Frame/Tag Command

- Function: Display/Set UART auto-frame Tag
- Format:
  - ◆ Query

**<Tag>**

- ◆ Set

**<Tag> [Enable/Disable]**

- Parameter:  
Set UART auto-frame tag. Only transmit data from tag head to tag tail. Filter the other datas. Setting is valid immediately.
  - ◆ Enable: Enable auto-frame tag function.
    - TagHead: LabelHead. Default: **0x55**, Single byte data.
    - TagTail: LabelTail. Default: **0xAA**, Single byte data.
  - ◆ Disable: Default: Value.

## 4.2.1.34. UART/Edit Command

- Function: Set UART parameter
- Format:
  - ◆ Set

**<Edit> [baudrate databits stopbits parity]**

- Parameter:  
Set all UART communication parameter including baud rate, data bit, stop bit and parity.

## 4.2.1.35. UART/Clean Command

- Function: Clear UART transmit-receive data information
- Format:
  - ◆ Set



**<Clean>**

- Parameter:  
Clear the UART data count(Data packet/Frame/Error packet and so on) shown in webpage.

## 4.2.1.36. SOCK Directory

- Function: Display/Set Socket channel directory.
- Format:
  - ◆ Tab key query

```
EPORT/SOCK>
Show      New      netp     UDP      quit
```

Netp and UDP are created socket channel. Itsupport maximum 5 Sockets.

## 4.2.1.37. SOCK/Show Command

- Function: Display Socket information function.
- Format:
  - ◆ Query

**<Show>**

## 4.2.1.38. SOCK/New Command

- Function: Set new Socket information
- Format:
  - ◆ Set

**<New> [name]**

- Parameter:
 

There is a default socket created(netp). It support max 5 socket channel. Every channel can be set as TCP/UDP/HTTP and so on. Setting is valid immediately.

  - ◆ Name: Socket name. Range 1~19 characters.
    - Input Sock Proto: Choose one communication method of the following.
      - TCP-SERVER: TCP Server Mode. It support max 5 TCP Client connection.
      - TCP-CLIENT: TCP Client Mode. It is used for connecting server.
      - UDP-SERVER: UDP Server Mode. Special function. Product will record the last received UDP package source IP and Port information. The received UART data will be send to this IP and port, not the setting DES3tination.
      - UDP-CLIENT: UDP Client Mode.
      - HTTP: HTTP Protocol transmission. The received UART data will transform to HTTP format and it will remove the HTTP header information and only output the HTTP data to UART.
      - TELNETD: Telnetd Mode. Use Telnet to config the UART Console equipment.
      - TLS: **Function is reserved. We will update it soon.**

**TCP Server Mode:**

- Input Local Port[0]: Set local port, Range 1~65535, 0 is random port. For TCP Server and UDP application, set it to a fixed 1~65535(TCP port 80 is used for its webpage). For TCP Client application, usually set it to 0.
- Input Buffer size[512]: Set Buffer size. Default: 512 bytes, Range:1~1400.
- Input KeepAlive[60]: Set TCP keepalive, Heartbeat time, Defalut 60s, Range: >=0.
- Input Timeout[300]: Set TCP timeout, If exceed setted time and don't received any network data package, It will break TCP connection. If working in TCP client mode, it will reconnect immediately. If it work in TCP server mode, the TCP client need to create the connction. Set this value to 0 is to close the function. The function is used for TCP to restore abnormal connection. Recommend to enable. Default: 300s, Range 0~600.
- Input Sock Security[Disable]: Security options, Used for data special encryption. Default: disable no encryption.
  - Disable: No encryption
  - TLS: TLS1.2 encryptioin, only support in TCP client mode.
  - AES: AES encryption, TCP/UDP all support this.
  - DES3: DES3 encryption, TCP/UDP all support this.
    - ◆ Input key: AES or DES3 key. For AES encryption, the key is fixed 16 bytes length, the IV value is the same as key. For DES3 encryption, the key is fixed 24 bytes length, the IV value the first 8 Bytes of key. The key can be ASCII or Hex format data. Hex format data need to use "space" character as separator, ex, "01 02 03..."
- Input Rout[uart]: Set the Socket channel output, Can choose UART and other created Socket or use as Log print using.

#### TCP Client Mode ( Only list out difference)

- Input Server Address: Set server IPv4 address or domain name.
- Input Server Port: Set server port
- Input Local Port[0]: Same as above
- Input Buffer size[512]: Same as above
- Input KeepAlive[60]: Same as above
- Input Timeout[300]: Same as above.
- Input Sock Security[Disable]: Same as above
- Set HeartBeat[Disable]: Set Heartbeat function, default is Disable
- Input HeartBeat Serial[F0FE6B1C3D35]: Set Heartbeat content, default is MAC address
- Input Connect Mode[Always]: Set TCP Client connection mode
  - Always: TCP persistent connection. If TCP break, it will reconnect immediately.
  - Burst: It will establish connection once UART received data. If set stop function, It will disconnect after network received stop data.
    - ◆ Input Stop Serial: Set Burst Mode Stop bits. It can be ASCII or Hex format data, Hex format data need use space as separator , 1~10 bytes.

- Input Rout[uart]: Same as above

**UDP Server/ UDP Client**

**HTTP Mode**

- Input HTTP type[POST]: HTTP request type. Default: POST. Can choose POST or GET.
- Input HTTP path[/]: HTTP request path, Need start by"/". The longest byte is 63 bytes.
- Input HTTP version[1.0]: HTTP Protocol Version. Default: 1.0, Can choose 1.0 or 1.1
- Input HTTP parameters: Add HTTP head information, end by "Enter" key.If want to end the input, direct input "Enter" key. All HTTP header data length should be less than 250 bytes.

4.2.1.39. SOCK/netp directory

- Function: Display/Set Socket netp channel directory.
- Format:
  - ◆ Tab key query

EPORT/SOCK/netp>	Name	Proto	Server	ServerPort
Show	BufSize	KeepAlive	Timeout	Security
LocalPort	ConnectMode	Rout	Save	Clean
HeartBeat	Quit			
Del				

Every created Socket channel can be modified through name. The above command function is the same as New Socket command description

4.2.1.40. SOCK/netp/clean Command

- Function: Clear netp channel data packets information
- Format:
  - ◆ Set

**<Clean>**

- Parameter:
 

The network data packets information can be checked from webpage. The command will reset the data count.

4.2.1.41. DATA Directory

- Function: Display/Set Cli command mode communication
- Format:
  - ◆ Tab Query

EPORT/DATA-Str>
Hex           Quit

Default: data sent in ASCII format. Also can change to send by HEX, The command is used for Cli command mode to transfer data.

4.2.1.42. Restart Command

- Function: Restart instruction.
- Format:

- ◆ Set

**<Restart>**

#### 4.2.1.43. Reload Instruction

- Function: Restore Factory setting instruction.
- Format:
  - ◆ Set

**Reload [SYS/UART/SOCK]**

- Parameter:  
Reload to factory setting, if add the following parameters, it will only restore corresponding parameters. Parameter can including one of the below three:
  - ◆ SYS: Restore system setting relevant paramter
  - ◆ UART: Restore UART setting relevant paramter
  - ◆ SOCK: Restore Socket relevant paramter

#### 4.2.1.44. Exit Command

- Function: Exit Cli Command mode instruction
- Format:
  - ◆ Set

**<Exit>**

#### 4.2.1.45. Quit Command

- Function: Quit the current and go the father Cli command directory.
- Format:
  - ◆ Set

**<Quit>**

#### 4.2.1.46. FwUpgrade Instruction

- Function: Upgrade product firmware.
- Format:
  - ◆ Set

**FwUpgrade [url]**

- Parameter:  
Do upgrade function, if upgrade success, it will feedback "Upgrade OK", if fail, output "Upgrade FAIL", reboot to run with new firmware if success
  - ◆ url: firmware url resources, Ex: http://192.168.0.101/mfw.bin

# APPENDIX A: REFERENCES

## A.1. Test Tools

IOTManager Configure Software:

<http://gb.hi-flying.com/downloadsfront.do?method=picker&flag=all&id=8c366199-b599-47a4-8d9c-20fa0b68bfcf&fileId=89&v=0.zip>

Overview of Characteristic	Parameters	Documents	Order Information
<b>Data Sheet</b>			
Title	Description	Version	Time
<a href="#">HF5111B User Manual</a>	HF5111B User Manual	1.0	2016.11.16
<a href="#">Eport&amp;HF51 Series Function and Cli Command</a>	Eport&HF51 Series Function and Cli Command	1.0	2016.10.21
<a href="#">Eport&amp;HF51 Series Application Manual</a>	Eport&HF51 Series Application Manual	1.0	2016.08.31
<a href="#">IOTManager Config Tools</a>	IOTManager Config Tools	2.5	2017.01.20

UART、Network Test software:

[http://www.hi-flying.com/download\\_list\\_dc/&downloadcategoryid=14&isMode=false&comp\\_stats=comp-FrontDownloadsCategory\\_show01-1376450727769.html](http://www.hi-flying.com/download_list_dc/&downloadcategoryid=14&isMode=false&comp_stats=comp-FrontDownloadsCategory_show01-1376450727769.html)

## B.3. Quick Start Manual

See our product application on website:

[http://www.hi-flying.com/products\\_detail/productId=96.html](http://www.hi-flying.com/products_detail/productId=96.html)

# APPENDIX B: TELNET COMMUNICATION FUNCTION

## B.1. Telnet Use Scene:


- a) Remote management device
- b) Remote management uart equipment

## B.2. Telnet Features:

- a) Telnet support echo mode,
- b) Telnet only support one Client port.
- c) Telnet port number is 23
- d) Telnet connected with TCP, If Client port don't transmit data in 300s, It will auto disconnect.


## B.3. Telnet Usage:

Telnet function default as ON, If can't connect, Pls use webpage or configuration to check the function is on or off.




Telnet	
Enable	<input checked="" type="checkbox"/>
Telnet Port	23
Echo	<input checked="" type="checkbox"/>


- a) Configure Secure CRT module and connect parameter, Equipment need to connect with LAN, Can use equipment LAN IP to access , If need remote to access the equipment, It need router have public IP address as port and mapped to internal website, Then can remote access equipment.



b) Use webpage account and password login in module, Then interface will show “EPORT>” .




c) Later use are same as UART cli command, And can realise Telnet data with UART data transparent transmission application.,



**Telnet Software implementation principle:**

Step 1 Establish TCP connection with module

Step 2 Module send “login”, Client port send user name(need end with Enter key,Tools can type Ctrl+Enter)




Step 3 Module send 0xFF 0xFB 0x01 Close telnet input display.

Step 4 Module send password, Client port send login password



Step 5 Module send 0xFF 0xFC 0x01 Open telnet input display



Step 6 It can send and receive Cli command After Enter into Cli command mode.

## APPENDIX C: CONTACT INFORMATION

---

**Address:** Room 1002,Building 1,No.3000,Longdong Avenue,Pudong New Area,Shanghai,China,201203

**Web:** [www.iotworkshop.com](http://www.iotworkshop.com) or [www.hi-flying.com](http://www.hi-flying.com)

**Contact:**

Sales: [sales@iotworkshop.com](mailto:sales@iotworkshop.com)

Support: [support@iotworkshop.com](mailto:support@iotworkshop.com)

Service: [service@iotworkshop.com](mailto:service@iotworkshop.com)

Business: [business@iotworkshop.com](mailto:business@iotworkshop.com)

---

For more information about IOTworkshop modules, applications, and solutions, please visit our web site [www.iotworkshop.com](http://www.iotworkshop.com)

**<END OF DOCUMENT>**

---