



eFamily Operation Instruction



Image 3

5. Control devices

Click the devices icon which you want to control on the home page (Say Wi-Fi socket)

① Click the socket control button, button in green means ON, Grey means OFF.




Image 1




Image 2

1. Please scan the QR code to download the App



iOS APP





Android APP

2. Account register

① Open the App eFamily, click "Register". Enter your phone number
Select your country code, so that you can receive a verification code.

② Enter the verification code

③ Set your password with 8 to 20 alphanumeric



3. Reset

Plug the product into a power outlet, press and hold the power button 6 seconds until the indicator light blink

② Timing set

Click "Timing" -- "Add", and set your ON/OFF timer



6. Multiple users management

System setting--Access control, add other user's account. The other user can connect the device with "Quick configuration"

Note

- ① If the devices can not connect on the App
Press and hold the power button 6 seconds, repeat Wi-Fi configuration when the indicator light blink.
- ② App compatible versions
Available for Android V4.3 and above, iOS 8.0 and above.
Some Android tablets may not compatible due to the peculiar Android OS.

4. Set up new devices

① Use your registered phone number (without country code) to log in the App, please select "Remote control" to log in by the first time

② Wi-Fi configuration

Click "+" on the home page top right corner, and click "Quick configuration", enter your Wi-Fi password



Image 1



Image 2

③ Click "Confirm"

Start searching the devices, The connected device icon will get displayed after search is completed
(Note: Please enter your Wi-Fi password correctly, if the Wi-Fi password is not correct, it will not get prompted, please do not include any punctuation in password)

③ Please make sure the devices are connected to the same Wi-Fi on which your smart phone is connected.

④ Router diagnose

- Our products do not support Web page authentication temporary.
- If your Wi-Fi router is Dual-band router, please select 2.4G network on phone to add the device. Also turn ON the Wi-Fi. Please do not hide it.
- Please set your router wireless encryption method as follows:
Type **WPA2-PSK**, authentication type: **AES**, or setting automatically. Wireless mode can not be **11n only**.
- To enable Wi-Fi router DHCP dynamic assignment IP service.
- AP Isolation unchecked.
- Please keep your router under good signal, please do not keep the device far away from your router.
- Please check the connected devices numbers. If it is above router limit then please close some connected devices and retry.