

# **5A, CC/CV Mode Step-Down Converter**

### DESCRIPTION

The EUP3467A is a step-down converter capable of driving 5A continuous load with excellent line and load regulation. The EUP3467A operates in either CC (Constant Current) mode or CV (Constant Voltage) mode with an input voltage range from 8V to 36V. The EUP3467A provides programmable cable compensation by adjusting external resistor divider. The EUP3467A stops switching when the output reaches over voltage threshold which is programmed by external resistor divider.

Fault protection includes secondary cycle-by-cycle current limit, short circuit protection and thermal shutdown. In shutdown mode the regulator draws  $3\mu A$  of supply current. Internal soft-start minimizes the inrush supply current and the output overshoot at initial startup.

The EUP3467A is available in SOP-8 (EP) package.

### **FEATURES**

- 8V to 36V Wide Input Operating Range
- 40V Input Voltage Surge
- Fixed 120kHz Switching Frequency
- CC/CV Mode Control
- Up to 5A Output Current
- +/- 1% Voltage Reference Accuracy
- +/- 4% Constant Current Accuracy
- Programmable Cable Compensation
- Internal Soft Start
- Output Over Voltage Protection
- Foldback Short Circuit Protection
- Secondary Cycle-by-Cycle Current Limit
- Thermal Shutdown
- Available SOP-8 (EP) Package
- RoHS Compliant and 100% Lead(Pb)-Free Halogen-Free

# **APPLICATIONS**

- Car Charger
- Portable charger applications
- DC/DC converters with current limited

# **Typical Application Circuit**





Figure 1. Application Circuit



**Pin Configurations** 




# **Pin Description**

Pin Name	SOP-8 (EP)	DESCRIPTION		
GND	1	Ground.		
FB	2	Output Feedback Input.		
ISEN-	3	Current sense negative input pin.		
ISEN+	4	Current sense positive input pin.		
SW	5	Power Switcher Output.		
VIN	6	Input Supply Pin.		
OVEN	7	OV (output over voltage) threshold setting pin. Drive OVEN voltage logic high to turn off the converter.		
COMP	8	Loop compensation pin.		
Thermal Pad	-	SW (Thermal Pad must be connected to the SW pin).		



# **Ordering Information**

Order Number	Package Type	Marking	Operating Temperature Range
EUP3467AWIR1	SOP-8 (EP)	<b>■</b> xxxxx 3467A	-40°C to +85°C



# **Block Diagram**




Figure 2. Functional Block Diagram



# **Absolute Maximum Ratings (1)**

•	Input Voltage (V <sub>IN</sub> )	-0.3V to 40V
•	Switch Voltage (V <sub>SW</sub> )	-1V to VIN +0.3V
•	ISEN+, ISEN	-0.3V to 13V
•	All Other Pins	-0.3V to 6V
•	Junction Temperature	150°C
•	Storage Temperature	-65°C to +150°C
	T 1 m (0 11 1 10 1)	26000

■ Lead Temp(Soldering, 10sec) ------ 260°C ■ Thermal Resistance  $\theta_{JA}$  (SOP-8\_EP) ------ 60°C /W

# **Recommend Operating Conditions (2)**

Note (1): Stress beyond those listed under "Absolute Maximum Ratings" may damage the device.

Note (2): The device is not guaranteed to function outside the recommended operating conditions.

# **Electrical Characteristics**


 $(V_{IN}=12V, T_A=+25$ °C,  $I_{OUT}=2.0A$ , unless otherwise specified)


Parameter	Conditions	EUP3467A			Unit
Parameter	Conditions	Min.	Typ.	Max.	Unit
Input voltage		8		36	V
Input No Load Current	I <sub>OUT</sub> =0A			10	mA
Quiescent Current	$V_{OVEN} = 0V, V_{FB} = 1.5V$		0.5	1	mA
Shutdown Current	$V_{OVEN} = 5V$		2.5		μΑ
Input Under Voltage Lockout Threshold Rising		6.2	6.7	7.2	V
Input Under Voltage Lockout Threshold Hysteresis			1		V
Current Limit			7		A
Operating fraquency		108	120	132	kHz
Operating frequency	$T_J = -25$ °C to $125$ °C	102		138	kHz
Maximum Duty Cycle				100	%
Minimum On-Time			400		ns
Deference Voltage of the Voltage Error Amplifier		1.168	1.18	1.192	V
Reference Voltage of the Voltage Error Amplifier	$T_J = -25^{\circ}C$ to $125^{\circ}C$	1.155		1.205	V
Defence as Voltage of the Comment Emen American		113	118	123	mV
Reference Voltage of the Current Error Amplifier	$T_J = -25$ °C to $125$ °C	111		125	mV
Transconductance of Error Amplifier			75		μA/V
Defends as Voltage of the Over Voltage Comments		1.145	1.18	1.215	V
Reference Voltage of the Over Voltage Comparator	$T_J = -25$ °C to $125$ °C	1.133		1.227	V
Reference Voltage of the Short Circuit Foldback Comparator			0.46		V
OVEN Shutdown Threshold Voltage		2.5			V
Thomas Chut down Tomas another	Temperature Rising		150		°C
Thermal Shut-down Temperature	Temperature Falling		100		°C
PMOS Drain-Source On-State Resistance	V <sub>IN</sub> =24V, I <sub>OUT</sub> =1A			90	mΩ





# **Typical Operating Characteristics**


 $V_{IN}$ =12V,  $V_{OUT}$ =5V,  $T_A$ =25°C, unless otherwise noted.















# **Typical Operating Characteristics (continued)**


 $V_{IN}$ =12V,  $V_{OUT}$ =5V,  $T_A$ =25°C, unless otherwise noted.







# Steady State $V_{IN}=12V,\ V_{OUT}=5V,\ I_{OUT}=5A$ $V_{OUT}$ 200mV/div $I_{L}$ 2A/div

4µs/div








# **Typical Operating Characteristics (continued)**


 $V_{IN}$ =12V,  $V_{OUT}$ =5V,  $T_A$ =25°C, unless otherwise noted.





# **Typical Operating Characteristics (continued)**

 $V_{IN}$ =12V,  $V_{OUT}$ =5V,  $T_A$ =25°C, unless otherwise noted.





# **Functional Description**

The EUP3467A is a current-mode step-down converter with 8V to 36V input power supply. The device can provide up to 5A continuous current to the output. The EUP3467A uses current-mode architecture to control the regulator loop. The output voltage is measured at FB through a resistive voltage divider and amplified through the internal error amplifier. The output current of the transconductance error amplifier is presented at COMP pin where a RC network compensates the regulator loop. Slope compensation is internally added to eliminate subharmonic oscillation at high duty cycle. The slope compensation adds voltage ramp to the inductor current signal which reduces maximum inductor peak current at high duty cycles.

# CC/CV mode control

The EUP3467A operates in either CC mode or CV mode. The CV mode regulates the output voltage. When output current reaches the CC threshold, the device enters CC mode to limit the output current.

### **Programmable cable compensation**

The EUP3467A provides programmable cable compensation by adjusting the external resistor divider to compensate resistive voltage drop across the charger's output cable.

### **Internal soft-start**

Internal soft-start minimizes the inrush supply current and the output overshoot at initial startup.

# Over voltage protection

OVP (over voltage protection) function with programmable OV (over voltage) threshold set by the external resistor divider is provided. When output over voltage occurs, the device shuts down and returns to normal operation automatically when the output over voltage is released.

# **Short circuit protection**

The EUP3467A provides the output short circuit protection function to prevent large output short circuit from damaging the device. When output short happens, the device shuts down and returns to normal operation automatically when the short circuit condition is released.

### **Thermal Shutdown**

The EUP3467A stops switching when its junction temperature exceeds  $150^{\circ}$ C and resumes when the temperature has dropped by  $50^{\circ}$ C to protect the device.

# **Application Information**

The output voltage is set through a resistive voltage divider and can be expressed by the equation as follows

$$V_{OUT} = 1.18V * (R3 + R4) / R4$$

### **Setting the CC current**

EUP3467A constant current value is set by the resistor R2 connected between the ISEN- and ISEN+ pins. The CC current is determined by the equation as follows

$$I_{CC} = 0.118 \text{V} / \text{R} 2$$

# Setting the output over voltage threshold

The OVEN pin voltage is set by a resistor divider connected between VOUT and GND. When OVEN pin voltage is higher than 1.18V, the regulator stops switching until OVEN pin voltage falls below 1.18V. Thus the output over voltage threshold is

$$V_{OV} = 1.18V * (R5 + R6)/R6$$

# **Setting the cable compensation**


The EUP3467A provides programmable cable voltage drop compensation using the impedance at the FB pin to compensate voltage drop across the charger's output cable. The cable compensation voltage can be expressed as

$$\Delta V_{OUT} = 5.27 \mu * I_{OUT} * R2 * R3$$

By adjust the value of R3, the cable compensation voltage can be programmed.



# **Packaging Information**



Remark: Exposed pad outline drawing is for reference only.

SYMBOLS	MILLIMETERS			INCHES		
SIMBOLS	MIN.	Normal	MAX.	MIN.	Normal	MAX.
A	1.35	-	1.75	0.053	-	0.069
A1	0.00	-	0.25	0.000	-	0.010
D	4.80	4.90	5.00	0.189	0.193	0.197
E1	3.70	3.90	4.00	0.146	0.154	0.157
D1	2.67	2.97	3.50	0.105	0.117	0.138
E2	1.78	2.18	2.60	0.070	0.086	0.102
Е	5.80	6.00	6.20	0.228	0.236	0.244
L	0.40	-	1.27	0.016	-	0.050
b	0.31	-	0.51	0.012	-	0.020
e	1.27 REF			0.050 REF		

